

Sicherheitshinweise: Setzen Sie dieses Produkt nicht Regen, Feuchtigkeit, Feuer oder übermäßigen Temperaturen aus. Feuer oder überhöhte Temperaturen können eine Explosion verursachen. Vermeiden Sie ein Herunterfallen oder Stöße, diese können das Gerät beschädigen.

Lampe während des Betriebs nicht abdecken. Außerhalb der Reichweite von Kindern aufbewahren und nur unter Aufsicht von Erwachsenen verwenden.

Verletzungsgefahr durch Selbsteingriffe und Zweckentfremdung.

Keine baulichen Veränderungen vornehmen. Nur für die vorgesehene Nutzung verwenden. Lichtstrahl nicht in die Augen halten und keine Lebewesen blenden.

Bewahren Sie Plastiktüten, Folien und andere Verpackungsmaterialien außerhalb der Reichweite von Kindern auf, da diese zum Ersticken führen können.

Reinigung, Instandhaltung, Pflege: Zur Reinigung genügt ein nebelfeuchtes, weiches und sauberes Tuch. Bei längerer Lagerung entnehmen Sie bitte die Batterien, um ein Auslaufen zu vermeiden. Lagern Sie das Gerät trocken, staubfrei und schützen Sie es vor extremer Hitze oder Kälte.

Mögliche Fehler / Fehlerbehebung: Falls die Taschenlampe nach dem Betätigen des AN Schalters nicht leuchtet, überprüfen Sie ob die Batterien noch funktionsfähig sind bzw. ob sie korrekt eingelegt sind.

Safety instructions: Do not expose this product to rain, moisture, fire or excessive temperatures. Fire or excessive temperatures can cause an explosion.

Avoid dropping or impact, as this may damage the appliance.

Do not cover the lamp during operation, keep it out of the reach of children and only use it under adult supervision. Risk of injury from tampering and misuse.

Do not make any structural changes. Only use for the intended purpose.

Do not point the light beam in the eyes and do not dazzle living creatures.

Keep plastic bags, foils and other packaging materials out of the reach of children, as they can cause suffocation.

Cleaning, maintenance, care: A damp, soft and clean cloth is sufficient for cleaning.

Please remove the batteries for longer periods of storage to prevent leakage.

Store the device in a dry, dust-free place and protect it from extreme heat or cold.

Possible faults / troubleshooting: If the torch does not light up after pressing the ON switch, check whether the batteries are still functional or whether they have been inserted correctly.